

## User Guide: Zelup® Gun

### Installation:

The installation of a Zelup® Gun is simple and quick.

Be sure to fulfill the following conditions:



To have a water connexion with a pressure between **0,5 and 1 bar**.  
(Barely open the tap or use a pressure reducer).  
The flow is auto-regulated by the connexion box of the Zelup® Gun



To have a compressor with a pressure between 6 and 10 bar.  
The minimum flow must be 200l/min and the maximum flow is auto-regulated by  
the connexion box of the Zelup® Gun.

You can also add an air filter between the compressor and the connexion box of the Zelup® Gun. For more information, contact us.

The air and water connections are directly made on the connexion box of the Zelup® Gun according to the following diagram:



- 1** Water filter
- 2** Water connection 3/4 M" BSP
- 3** Pressured air connection 1/4 F" BSP

## Use:

The Zelup® Gun is a 3 in 1 high pressure cleaning system. This patented system allows you to wash, brush and dry safely without any splashing.

### Position 1 : Washing

To wash, pull the trigger to the maximum (see following diagram).  
The Zelup® Gun will then propel its air/water mix



The brush at the end Zelup® Gun allows you to scrub while washing or not.

### Position 2 : Drying

To dry, put the trigger to its middle position (see following diagram).  
Le Zelup® Gun will then propel air under high pressure.

